

PCU Firmware Updating Instructions

You will need:

- A Macintosh computer running OS X 10.5 or later with at least one free USB port
- A USB A-B cable:



Instructions:

- Download the latest PCU firmware installer and uncompress the .zip file (You probably already did this).
- On the PCU, remove the plastic cap covering the USB port on the side with the lens connector:



- Connect the PCU to the Mac with USB cable. The PCU should now power on.
- Open the folder called vXX (where XX is the current firmware build) and double-click the file called "loadpcufirmware.command". A Terminal window should open and several commands should execute. After about a minute, you should see "[Process completed]" in the Terminal window, and the PCU will reboot. You should see the current revision number on the boot screen.

Troubleshooting:

- If the loading process completes almost instantly without showing any progress, check that the USB cable is fully seated in receptacle in the PCU. Note that some cables are too thick to fit entirely through the hole in the PCU body.