

PCU2 Firmware Updating Instructions

You will need:

- A Macintosh computer running OS X 10.6 or later with at least one free USB port
- A USB2 A-B cable



Instructions:

- Download the latest PCU firmware installer
- Decompress the .zip file by double clicking it in the finder
- Connect the PCU2 to the Mac with the USB cable.



- Power on the PCU2.
- Open the folder called vXXX (where XXX is the current firmware build) and double-click the file called "loadpcufirmware.command". A Terminal window should open and several commands should execute. After about a minute, you should see "[Process completed]" in the Terminal window, and the PCU2 will reboot. You should see the current revision number on the boot screen.

Troubleshooting:

- If the loading process completes almost instantly without showing any progress, check that the USB cable is fully seated in receptacle in the PCU2.